

Receiver Lock and Key Safe

**Coffre-fort et verrou
Cerrojo receptor y caja de seguridad**

Combination Reset Instructions

The lock is preset to open at 0-0-0-0

1. Align the opening combination and slide change lever over.
2. This will cause the reset button to pop up.
3. Set the dials to the desired combination.
4. Push the reset button down to complete the change.
5. Write down the new combination or register it online at www.masterlock.com.

Instructions pour le changement de la combinaison

Le verrou est pré-réglé pour ouvrir
sur 0-0-0-0

1. Aligner la combinaison en vigueur et faire glisser le levier de changement.
2. Le bouton de réarmement se soulèvera.
3. Faire tourner les roulettes à la combinaison désirée.
4. Appuyer sur le bouton de réarmement pour compléter le changement.
5. Noter par écrit la nouvelle combinaison ou l'enregistrer en ligne sur www.masterlock.com

Instrucciones para cambiar la combinación

El cerrojo viene prefijado para abrirse con 0-0-0-0

1. Alinee la combinación de apertura y desplace la palanca de cambio.
2. Esto hará que se levante el botón de restablecimiento.
3. Fije los selectores en la combinación deseada.
4. Pulse el botón de restablecimiento hacia abajo para terminar de hacer el cambio.
5. Anote la nueva combinación o regístrela en línea en www.masterlock.com

