

INSTALLATION MANUAL



SETUP

- 1. Download the app Search 'BetterWeigh' in the Google Play or iOS App Store and install.
- 2. Installation

 BetterWeigh™ is compatible with OBD-II equipped vehicles (US 1996 and newer). Plug the BetterWeigh™ into the diagnostic port, typically located below the steering wheel, near the driver's door.

REGISTRATION & WARRANTY

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

Functionality on manual transmission vehicles limited to payload, tongue weight, pin weight and weight distribution



NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

- Increase the separation between the equipment and receiver
- Consult the dealer or an experienced radio / TV technician for help

BetterWeigh™ only allows one Bluetooth connection. Any other vehicle sync functions will not work when using the app. This is to reduce the 'noise' during calibration.

Vehicle should be warmed up prior to running weigh features.

MARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

